



1. GreenCoat PLX Pro BT.
2. Breather Membrane.
3. 18mm WBP plywood.
4. Eaves flashing lapped and sealed end to end.
5. Flashing liner.
6. Insect mesh.
7. Eaves gutter.
8. Capping.
9. Single lock fascia.
10. Single lock soffit.
11. Abutment flashing.